



PART NUMBER

**PFF80-1210**

DESCRIPTION

**REAR TRAILING ARM - FRONT BUSH**

**INSTALLATION GUIDE**

**Contents (parts per pack):**

- 2 x bushes (2 x A parts & 4 x B parts)
- 2 x metal sleeves
- 1 x grease



A part

B part



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove the rear trailing arm from the car.
2. Remove the original bush from the arm, clean any rust and burrs from the arm.
3. Apply some washing up liquid to the tapered edge of the 80-1210A part, insert the tapered end into the hole in the arm from the radius side and press the bush through the arm.
4. Apply some of the supplied grease to the bore of the A part. Insert two 80-1210B parts into the A part, one from each side.
5. Apply some of the supplied grease to the bore of the B parts and push the stainless steel sleeve through the bush.
6. Refit the arm to the car.

