

POWERFLEX®

PART NUMBER

PFR80-1215

DESCRIPTION

REAR LOWER ARM OUTER BUSH TO HUB

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes
- 2 x metal sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove original bush from rear upright.
2. Fit new bush to upright, insert the end of the bush with the chamfer into the chamfered end of the hole of the upright.

Tip: apply washing up liquid to new bush.

3. Apply some of the supplied grease into the bore of the bush and the outside of the stainless steel sleeve, fit the sleeve into the bush.
4. Refit the lower arm.

