

POWERFLEX®

PART NUMBER

PF57K-1002G

DESCRIPTION

TRACK CONTROL ARM AND BUSH KIT

INSTALLATION GUIDE

Contents (parts per pack):

1 x C45 Spanner 1 x 34AF Spanner
4 x Stainless Steel Washers

Pre-assembled parts:

2 x Cast Aluminium Track Control Arms
2 x Outer Bushes 4 x Inner Bushes
2 x Long Adjustable Stainless Steel Sleeves
2 x Ball Joint Nuts
2 x Short Adjustable Stainless Steel Sleeves

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tightened to manufacturer's torque settings.*

Fitting Instructions:

1. Loosen and remove vertical bolt from outer bush on the original arm on the car, and slide control arm link away from bush.
2. Loosen and remove the horizontal bolt from the inner bush on the original arm, and drop the arm down to hang from the ball joint.
3. With the increased room to work, the ball joint nut will be accessible. Loosen this with a spanner and torx bit, and it may then need to be pushed out with a ball-joint separator.
4. Remove plastic ball joint cover from the Powerflex arm, and fit the ball joint onto the hub carrier with the supplied nut. The ball joint may need a few taps with a soft hammer to seat. Tighten to manufacturer's recommended torque spec.
5. Slide the end of the control arm link over the outer bush on the Powerflex arm, and slide the bolt through to hold it in place. Loosely thread the nut onto the bolt.
6. Slide a washer over the small end of inner bush sleeve, and then push inner bush of the arm into the mounting point on the subframe, and slide bolt through to hold it in place. Thread the nut onto the bolt. The arm may need a few taps with a soft hammer to sit in place.
7. With the bolt for the inner bush still loose, adjust camber angle on the inner sleeve with the C45 spanner according to Figure 2.
8. After reaching desired camber angle, adjust the caster angle on the inner sleeve with the 34AF spanner according to Figure 1.
9. Tighten both bolts on the arm to manufacturers recommended torque settings.


Note: Points 7 & 8 may require alignment equipment to ensure wheel geometry is correct, and other wheel alignment parameters will need to be checked and corrected after this kit is fitted.



Remove the outer bush bolt securing control arm link to arm



Remove the inner bush bolt



Drop the arm down to access the Ball joint




Figure 1: Outer Bush Caster Adjustment - Sleeve Position for maximum negative camber




Figure 2: Inner Bush Orientation and Camber Adjustment