

POWERFLEX®

PART NUMBER

PFF44-502

DESCRIPTION

FRONT WISHBONE REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes 1 x PTFE/Silicone Grease
2 x Stainless Steel Sleeves 2 x Zinc Plated Steel Outer Shells

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original rubber bush and metal outer shell from the front wishbone arm. Clean any dirt and corrosion from the bore of the arm and file off any sharp edges.

2. Press in the zinc plated steel outer shell into the bore of the arm with the smaller diameter being pushed in first from the top of the arm, as shown in Figure 1.

Tip: apply some washing up liquid on the polyurethane bush to allow ease of fitting and press fit the bush at an angle so that part of the lip is already in the bore of the arm (Figure 2).

3. Press in the polyurethane bush into the zinc plated steel outer shell, with the smaller lip diameter of the polyurethane bush being pushed in first so that the larger diameter of the bush and the larger diameter of the outer shell sits flush together (Figure 3).

4. Apply some of the supplied grease into the bore of the polyurethane bush and fit the stainless steel sleeve into the bore of the bush until it's flush.

5. Refit the front wishbone arm back to the vehicle and tension all hardware to manufacturers recommended torque settings.






Figure 1 - how the polyurethane parts fit inside the wishbone arm



Figure 2




Figure 3